

Step 3:

Install wall connector covers and mullion covers



Transom mullion covers are installed after mullion and wall connector covers

Mullion covers are installed after doors are fully functional.

Wall Connector Trim can be turned either way to cover front edge

Tips:

- Minimally expanding foam can be used to seal around frames once doors are fully functional
- Use a quality sealant to adhere and seal trim in place.